

kicad

Kicad

PI_Editor

Reference manual

Copyright

This document is Copyright ©2013 by it's contributors as listed below. You may distribute it and/or modify it under the terms of either the GNU General Public License (<http://www.gnu.org/licenses/gpl.html>), version 3 or later, or the Creative Commons Attribution License (<http://creativecommons.org/licenses/by/3.0/>), version 3.0 or later.

Contributors

Jean-Pierre Charras.

Feedback

Please direct any comments or suggestions about this document to the KiCad mailing list:
<https://launchpad.net/~kicad-developers>

Publication version

July 10, 2013.

Table of Contents

1 - Introduction to PI_Editor.....	3
2 - PI_Editor files.....	3
2.1 - Input file and default title block.....	3
2.2 - Output file.....	4
3 - Theory of operations.....	4
3.1 - Basic page layout items properties:.....	4
3.2 - Coordinates definition.....	4
3.3 - Reference corners and coordinates:.....	4
3.4 - Rotation.....	5
3.5 - Repeat option.....	6
4 - Texts and formats.....	6
5 - Constraints.....	7
5.1 - Page 1 constraint.....	7
5.2 - Text full size constraint.....	8
6 - Invoking PI_Editor.....	8
7 - PI_Editor Commands.....	8
7.1 - Main Screen.....	8
7.2 - Main Window Toolbar.....	9
7.3 - Commands in drawing area (draw panel).....	10
7.3.1 - Keyboard Commands.....	10
7.3.2 - Mouse Commands.....	10
7.3.3 - Context Menu.....	10
7.4 - Status Bar Information.....	11
8 - Left window.....	11
9 - Right window.....	12
10 - Interactive edition.....	14

1 - Introduction to PI_Editor

PI_Editor is a page layout editor tool to create custom title blocks, and frame references. The title block, associated to frame references, and other graphic items (logos) is called here a page layout

Basic page layout items are:

- Lines
- Rectangles
- Texts (with format symbols, which will be replaced by the actual text, like the date, page number...) in Eeschema or Pcbnew.
- Poly-polygons (mainly to place logos and special graphic shapes)

Items can be repeated, and texts and poly_polygons can be rotated.

2 - PI_Editor files

2.1 - Input file and default title block

PI_Editor reads or writes page layout description files *.kicad_wks (kicad **worksheet**). An internal default page layout description to display the default Kicad title block is used until a file is read

2.2 - Output file

The current page layout description can be written in a *.kicad_wks file, using the S expression format, which is widely used in Kicad.

This file can be used to show the custom page layout in Eeschema and/or Pcbnew.

3 - Theory of operations

3.1 - Basic page layout items properties:

Basic page layout items are:

- **Lines**
- **Rectangles**
- **Texts** (with format symbols, with will be replaced by the actual text, like the date, page number...) in Eeschema or Pcbnew.
- **Poly-polygons** (mainly to place logos and special graphic shapes) these poly polygons are created by Bitmap2component, and cannot be built inside pl_editor, because it is not possible to create such shapes by hand.

Therefore

- **Texts and poly-polygons** are defined by a position, and can be rotated.
- **Lines** (in fact segments) and **rectangles** are defined by two points: a start point and a end point.
They cannot be rotated (this is useless for segments)

These basic items can be repeated.


Texts which are repeated accept also an increment value for labels (has meaning only if the text is one letter or one digit)

3.2 - Coordinates definition

Each position, start point and end point of items is always relative to a page corner.

This feature ensure you can define a page layout which is not dependent on the paper size.

3.3 - Reference corners and coordinates:





- When the page size is changed, the position of the item, relative to its reference corner does not change.
- Usually, title blocks are attached to the right bottom corner, and therefore this corner is the default corner, when creating an item.

For rectangles and segments, which have two defined points, each point has its reference corner.

3.4 - Rotation

Items which are a position defined by one point (texts and poly-polygons) can be rotated:






Rotated: Rotation = 20 and 10 degrees.

3.5 - Repeat option

Items can be repeated:

This is useful to create grid and grid labels.



4 - Texts and formats

Texts can be simple strings or can include format symbols.

Format symbols are replaced by the actual values in Eeschema or Pcbnew.

They are like format symbols in printf function.

A format symbol is % followed by 1 letter.

The %C format has one digit (comment identifier)

Formats symbols are:

%% = replaced by %
%K = Kicad version
%Z = paper format name (A4, USLetter ...)
%Y = company name
%D = date
%R = revision
%S = sheet number
%N = number of sheets
%Cx = comment (x = 0 to 9 to identify the comment)
%F = filename
%P = sheet path (sheet full name, for Eeschema)
%T = title

example:

"Size: %Z\" displays "Size A4" or Size USLetter"

Sheet: File: Title: Size: A4 Date: + KiCad E.D.A. pL_Editor (2013-07-16 BZR 4245)-test 4 5	User display mode:  activated. Title block displayed like in Eeschema and Pcbnew
%%C0 %Y Sheet: %P File: %F Title: %T Size: %Z Date: %D %K 4 5	"Native" display mode:  activated. The native texts entered in PL_Editor, with their format symbols.


5 - Constraints

5.1 - Page 1 constraint

When using Eeschema, the full schematic often uses more than one page.

Usually layout items are displayed on all pages.


But if a user want some items to be displayed only on page 1, or not on page 1, the "page 1 option" this is possible by setting this option:



Page 1 option:

- None: no constraint.
- Page 1 only: the items is visible only on page 1
- Not on page 1: the items is visible on all pages but the page 1

5.2 - Text full size constraint



Only for texts, one can set 2 parameters :

- the max size X
- the max size Y

which define a bounding box

When these parameters are not 0, when displaying the text, the actual text height and the actual text width are dynamically modified if the full text size is bigger than the max size X and/or the max size Y, to fit the full text size with this bounding box.

When the actual full text size is smaller than the max size X and/or the max size Y, the text height and/or the text width is not modified.

	The text with no bounding box. Max size X = 0 Max size Y = 0
	The same text with constraint. Max size X = 40 Max size Y = 0


6 - Invoking PI_Editor

PI_Editor is typically invoked from a command line, or from the Kicad manager. From a command line, the syntax is `pl_editor <*.kicad_wks file to open>`.

7 - PI_Editor Commands

7.1 - Main Screen

The image below shows the main window of PI_Editor.



The left pane contains the list of basic items.

The right pane is the item settings editor.

7.2 - Main Window Toolbar.



The top toolbar allows for easy access to the following commands:

	Select the net list file to be processed.
	Load a page layout description file.
	Save the current page layout description in a .kicad_wks file.
	Display the page size selector and the title block user data editor.
	Prints the current page.
	Delete the currently selected item.
	Undo/redo tools.

	Delete all footprint assignments.
	Show the page layout in user mode: texts are shown like in Eeschema or Pcbnew: text format symbols are replaced by the user texts.
	Show the page layout in native mode: texts are displayed “as is”, with the contained formats, without any replacement.
Right Bottom page corner ▾	Reference corner selection, for coordinates displayed to the status bar..
	Selection of the page number (page & or other pages). This selection has meaning only if some items have a page option, are shown on all pages (in a schematic for instance, which contains more than one page)

7.3 - Commands in drawing area (draw panel)

7.3.1 - Keyboard Commands


F1	Zoom In
F2	Zoom Out
F3	Refresh Display
F4	Move cursor to center of display window
Home	Fit footprint into display window
Space Bar	Set relative coordinates to the current cursor position
Right Arrow	Move cursor right one grid position
Left Arrow	Move cursor left one grid position
Up Arrow	Move cursor up one grid position
Down Arrow	Move cursor down one grid position

7.3.2 - Mouse Commands

Scroll Wheel	Zoom in and out at the current cursor position
Ctrl + Scroll Wheel	Pan right and left
Shift + Scroll Wheel	Pan up and down
Right Button Click	Open context menu

7.3.3 - Context Menu

Displayed by right-clicking the mouse:



- Add line
 - Add rect
 - Add text
 - Import poly descr file
- are commands to add a basic layout item to the current page layout description.


You cannot add a polygon here (because usually it needs hundred of vertices).

You only can Import a poly description file, created by Bitmap2Component.

- Zoom selection: Direct selection of the display zoom
- Grid selection: Direct selection of the grid.

7.4 - Status Bar Information

The status bar is located at the bottom of the PI_Editor and provides useful information to the user.



Coordinates are **always relative to the corner** selected as **reference**.


8 - Left window

The left window shows the list of layout items.

One can select a given item (left clicking on the line), or when right clicking on the line, display a pop up menu

This menu allows basic operations: add a new item, or delete the selected item.

→ A selected item is also drawn in Yellow on draw panel.



Design tree: the item 19 is selected, and shown in Yellow on the draw panel.

9 - Right window

Properties

Item Properties	General Options	
Type	Page 1 option	
<input type="text"/>	<input type="button" value="None"/>	
Text		
<input type="text"/>		
H justification	<input type="button" value="Left"/>	<input type="checkbox"/> Bold
V justification	<input type="button" value="Center"/>	<input type="checkbox"/> Italic
Text Height (mm)	Text Width (mm)	
<input type="text"/>	<input type="text"/>	
Constraints:		
Max Size X (mm)	Max Size Y (mm)	
<input type="text"/>	<input type="text"/>	
<input type="button" value="Accept"/>		
Comment		
<input type="text"/>		
Pos X (mm)	Origin	
<input type="text"/>	<input type="button" value="Lower Right"/>	
Pos Y (mm)		
<input type="text"/>		
End X (mm)	Origin	
<input type="text"/>	<input type="button" value="Lower Right"/>	
End Y (mm)		
<input type="text"/>		
Thickness	Set to 0 to use default	
<input type="text"/>		
Rotation	<input type="text"/>	
Repeat parameters:		
Repeat count	Text Increment	
<input type="text"/>	<input type="text"/>	
Step X (mm)	Step Y (mm)	
<input type="text"/>	<input type="text"/>	

Properties

Item Properties	General Options
Default Values:	
Text Size X (mm)	Text Size Y (mm)
<input type="text" value="1,500"/>	<input type="text" value="1,500"/>
Line Thickness (mm)	Text Thickness
<input type="text" value="0,150"/>	<input type="text" value="0,150"/>
Page Margins	
Left Margin (mm)	Right Margin (mm)
<input type="text" value="10,000"/>	<input type="text" value="10,000"/>
Top Margin (mm)	Bottom Margin (mm)
<input type="text" value="10,000"/>	<input type="text" value="10,000"/>
<input type="button" value="Accept"/>	

The right window is the edit window.
One can set properties of the page and properties of the current item.

Displayed settings depend on the selected item:


<p style="text-align: right;">Accept</p> <p>Type Page 1 option Line None</p> <p>Comment</p> <p>Pos X (mm) Origin 50,000</p> <p>Pos Y (mm) Upper Left 2,000</p> <p>End X (mm) Origin 50,000</p> <p>End Y (mm) Upper Left 0,000</p> <p>Thickness 0,000 Set to 0 to use default</p> <p>Repeat parameters: Repeat count 30</p> <p>Step X (mm) Step Y (mm) 50,000 0,000</p>	<p style="text-align: right;">Accept</p> <p>Type Page 1 option Text None</p> <p>Text %K</p> <p>H justification Left <input type="checkbox"/> Bold V justification Center <input type="checkbox"/> Italic</p> <p>Text Height (mm) Text Width (mm) 0,000 0,000</p> <p>Constraints: Max Size X (mm) Max Size Y (mm) 0,000 0,000</p> <p>Comment</p> <p>Pos X (mm) Origin 109,000</p> <p>Pos Y (mm) Lower Right 4,100</p> <p>Thickness 0,000 Set to 0 to use default</p> <p>Rotation 0,000</p> <p>Repeat parameters: Repeat count Text Increment 1 1</p> <p>Step X (mm) Step Y (mm) 0,000 0,000</p>	<p style="text-align: right;">Accept</p> <p>Type Page 1 option Poly Page 1 only</p> <p>Comment</p> <p>Pos X (mm) Origin 136,002</p> <p>Pos Y (mm) Lower Right 18,002</p> <p>Thickness 0,010</p> <p>Rotation 20,000</p> <p>Repeat parameters: Repeat count 1</p> <p>Step X (mm) Step Y (mm) 0,000 0,000</p>
Settings for lines and rectangles	Settings for texts	Settings for poly-polygons

10 - Interactive edition


An item can be selected:

- From the Design tree.
- By Left clicking on it.
- By Right clicking on it (and a pop up menu will be displayed).

When selected, this item is drawn in Yellow.



When right clicking on the item, a pop-up menu is displayed.
The pop menu options slightly depend on the selection:



If more than one item is found, a menu clarification will be shown, to select the item:

